BLUETOOTH Remote Control

Remote Control - C

Remote Control - D

Capture Mode

Record Button

BLUETOOTH / Power Button

Camera Mode

BLUETOOTH / Power Button

Record Button

Record Button - Start/Stop Video, Capture Photo &
Pair BLUETOOTH/Power Button

BLUETOOTH/Power Button - For pairing via BLUETOOTH or powering camera on/off

Camera Mode - Video or Photo

Capture Mode - 360° Spherical Photo VR Mode (Lens A & Lens B), 197° 4K Ultra Wide Mode & 235° Dome Mode

BLUETOOTH Remote Control Instructions

Pairing the Cameras and Remote Controls:

1. This method is for one remote control to one camera: With the camera turned on, press the ⬛ button for 2 seconds to enter the pairing mode.

Remote Pair Setting → Press ⏻ & REC keys for 5 secs to pair...

Press ⏻ & REC keys for 5 secs to pair... → Connecting and setting device Please wait ...

Press and hold the ⬛ and 🔴 buttons on the remote control simultaneuosly until pairing is successful.

While pairing, the remote control should be close to the camera.

Successful Pairing!

2. Press the 🔴 button on the remote control to start shooting or recording and press the 🔴 button again to stop recording.

Other camera settings and parameters remain the same as preselected movie or still camera settings.

3. To turn the camera off, press the ⬛ button.

kodakpixpro.com